



NASA®  
electric  
MULTI-FUNCTIONAL COOKER  
NS-3074



دفترچه راهنمای استفاده از پلویز چندکاره و کارت گارانتی محصول

لوازم خانگی ناسا الکتریک®



## Multi-functional Cooker NS-3074





## دفترچه راهنمای استفاده از پلویز چند کاره ناسا الکتریک NS-3074

مشتری گرامی از حسن سلیقه و اعتماد شما به برند ناسا الکتریک سپاسگزاریم.  
این دفترچه راهنمای استفاده از پلویز چند کاره ناسا الکتریک مخصوص دستگاه NS-3074  
دستگاه تهیه شده است. لطفاً قبل از استفاده از دستگاه، دفترچه راهنمای را با  
دقت مطالعه کرده و برای استفاده‌های بعدی نگذارید.



## فهرست

## صفحه

۴	هشدارهای مهم ایمنی.....
۵	قطعات و متعلقات دستگاه.....
۶	راهنمای استفاده از دستگاه.....
۸	راهنمای کار با کنترل پنل.....
۱۰	راهنمای استفاده از برنامه‌های پخت.....
۱۳	عیب‌یابی.....
۱۴	راهنمای تمیز کردن و نگهداری دستگاه.....
۱۴	مشخصات فنی دستگاه.....
۱۴	گارانتی و خدمات پس از فروش.....



**NS-3074**  
Multi-functional  
cooker

۱۲. از جابه‌جا کردن دستگاه حین کار خودداری کنید. در صورت نیاز به جابه‌جایی، ابتدا دستگاه را خاموش کرده سپس دوشاخه را از پریز برق بیرون آورید.

۱۳. جهت جلوگیری از خطر برق گرفتگی هرگز با دست خیس دوشاخه را به پریز برق وصل نکرده و بدنی دستگاه را مس نکنید.

۱۴. هنگام استفاده از دستگاه، بدنی دستگاه گرم می‌شود و احتمال خروج بخار از دریچه‌ی تخلیه بخار وجود دارد، جهت جلوگیری از آسیب‌های احتمالی، فاصله‌ی استاندارد را از بدن و دریچه‌ی تخلیه بخار دستگاه رعایت کنید.

۱۵. حین روشن بودن دستگاه، هرگز دریچه‌ی تخلیه بخار یا بدنی دستگاه را با دستمال یا هر شیء دیگری نپوشانید.

۱۶. از این دستگاه در کنار عوامل آتش‌زا، منفجر شونده یا در محیط‌های مطروب استفاده نکنید.

۱۷. برای محافظت از روش قابلمه و جلوگیری از تغییر شکل آن، برنج یا مواد غذایی دیگر را در ظرف دیگری بشویید سپس داخل قابلمه پخت بپرسید.

۱۸. اطمینان حاصل کنید که برنج یا هر ماده‌ی غذایی دیگری بر روی المنت زیر قابلمه‌ی پخت نباشد. در صورت وجود، ابتدا آن را تمیز کنید سپس قابلمه را داخل دستگاه قرار دهید.

۱۹. قبل از استفاده از دستگاه، از نحوه‌ی صحیح قرار گرفتن قابلمه پخت داخل دستگاه مطمئن شویید. می‌بایست اتصال کامل بین المنت و قابلمه پخت برق را باشد.

۲۰. به طور منظم درپوش داخلی و واشر نشت‌گیر را بعد از هر بار استفاده بشویید تا از ایجاد بوی بد ناشی از تماننده‌ی مواد غذایی جلوگیری شود.

۲۱. در صورت عدم استفاده‌ی طولانی مدت از دستگاه، ابتدا دستگاه را خاموش کنید. دوشاخه را از پریز برق بیرون آورید و دستگاه را در مکانی خشک و دارای تهویه نگه دارید.

۲۲. در صورت خرابی کابل برق، هرگز از دستگاه استفاده نکنید زیرا ممکن است منجر به شوک الکتریکی شود.

۲۳. در صورت نیاز کابل را از مراکز مجاز خدمات پس از فروش ناسا الکتریک خریداری کنید. هرگز نباید کابل توسط خود فرد تعمیر و تعویض دریچه‌ی تخلیه بخار به درستی نصب شده است.

## هشدارهای مهم ایمنی

لطفاً قبل از استفاده از دستگاه، هشدارهای مهم ایمنی، راهنمای نصب قطعات و راهنمای استفاده از دستگاه را مطالعه کنید.

۱. قبل از استفاده از دستگاه برسی کنید که ولتاژ برق منطقه شما با ولتاژ برق نوشته شده بر روی دستگاه مطابقت داشته باشد.

۲. این وسیله برای استفاده توسط افراد (از جمله کودکان) با ناتوانی فیزیکی، حسی و عقلی یا افراد بتجربه و ناگاه طراحی نشده است. مگر اینکه با حضور سپرپست مسئول در قبال ایمنی آنها و نظارت یا دستورالعمل استفاده از وسیله باشد.

۳. کودکان باید سرپرستی و نظارت شوند تا اطمینان حاصل شود که با وسیله بازی نمی‌کنند.

۴. این وسیله برای مصارف خانگی و موارد مشابه طراحی شده است و برای مصارف صنعتی مناسب نمی‌باشد.

۵. قبل از استفاده از دستگاه برای اولین بار، همه‌ی قسمت‌های در تماس با مواد غذایی را با آب و مواد شوینده نشویید.

۶. در صورت بروز هر گونه مشکل و خرابی در هر یک از اجزای دستگاه اعم از کابل تغذیه و دوشاخه هرگز از دستگاه استفاده نکرده و فوراً با یکی از نزدیکترین مراکز خدمات پس از فروش ناسا الکتریک تماس بگیرید یا دستگاه را به مرکز ارسال نمایید.

۷. در صورت خرابی یک قطعه از اجزای دستگاه خودسرانه آن را با قطعات مشابه تعویض نکنید و حتماً با خدمات پس از فروش ناسا الکتریک تماس بگیرید. (لطفاً جهت کسب اطلاعات بیشتر با شماره ۰۲۴۵۱۱۲ تماس بگیرید.)

۸. از این وسیله در مکان‌هایی که سیم اتصال به زمین (ارت) وجود ندارد، استفاده نکنید.

۹. فقط از قابلمه‌ی پخت اصلی دستگاه استفاده کنید، از قابلمه‌های غیر استاندارد به هیچ وجه استفاده نکنید.

۱۰. قبل از قرار دادن قابلمه‌ی پخت داخل دستگاه یا هنگامی که هنوز قابلمه خالی است، دستگاه را روشن ننمایید.

۱۱. قبل از شروع پخت اطمینان حاصل کنید، دریچه‌ی تخلیه بخار به درستی نصب شده است.

راه دور یا تایمیر مجزا در نظر گرفته نشده است.

**۲۵**. قبل از تمیز کردن دستگاه جهت جلوگیری از سوختگی، ابتدا آن را خاموش کرده سپس دوشاخه را از پریز برق بیرون آورید و منتظر باشید تا دستگاه خنک شود.

**۲۶**. در هنگام کار با دستگاه در دفعات اول ممکن است متوجه بوی غیر معمول شوید این امر طبیعی بوده و پس از چند بار استفاده از دستگاه این مشکل رفع خواهد شد.

شود.

**۲۳**. هنگامی که پلویز روشن است، از باز کردن درب آن خودداری کنید. بعد از اتمام برنامه‌ی پخت، دوشاخه را از پریز برق بیرون آورید سپس درب آن را باز کنید.

**۲۴**. دریوش تخلیه‌ی بخار را پس از هر بار استفاده تمیز کنید تا از مسدود شدن دریچه‌ی تخلیه بخار جلوگیری شود.

\* این دستگاه به منظور کار با سیستم کنترل از قطعات و متعلقات دستگاه



۲. کلید باز کردن درب را فشار دهید، تا درب پلویز باز شود و قابلمه‌ی پخت را از داخل محفظه‌ی داخلی دستگاه بیرون آورید. (مطابق تصاویر ۱-۲)

۳. مواد غذایی مورد نظر را داخل قابلمه‌ی پخت بریزید و قابلمه را درون دستگاه قرار دهید.  
• حداکثر ظرفیت قابلمه‌ی پخت ۵ لیتر می‌باشد و ظرفیت قابل استفاده‌ی آن ۴ لیتر است.

• بر روی دیواره‌ی داخلی قابلمه‌ی پخت درجه‌بندی دقیقی وجود دارد، که برای اندازه‌گیری میزان آب و مواد غذایی استفاده می‌شود. دقت داشته باشید که میزان آب و مواد غذایی داخل قابلمه‌ی پخت نباید بیشتر از خط "MAX" روی قابلمه‌ی پخت باشد.

۴. قابلمه را در جای خود بر روی المنت قرار دهید. قبل از گذاشتن قابلمه بر روی المنت، مطمئن شوید که هیچ شیئی بر روی المنت و درون محفظه‌ی داخلی وجود نداشته باشد. (مطابق تصویر ۱-۳)

۵. دریوش داخلی را در جهت درست (واشر نشت‌گیر رو به بیرون باشد) به درب پلویز وصل کنید.

• اندتا دو ضامن دریوش داخلی را درون شیارهای مربوطه بر روی درب قرار دهید، سپس دو گیره‌ی انتهای دریوش داخلی را به سمت پایین فشار دهید، تا در جای خود محتمم شود. (مطابق تصویر ۱-۴)

۶. درب دستگاه را به سمت پایین فشار دهید، تا صدای تیک شنیده شود. (مطابق تصویر ۱-۵)

۷. دریچه‌ی تخلیه‌ی بخار و دریوش آن را بررسی کنید که به درستی در جای خود قرار گرفته باشند. در صورتی که دریچه‌ی تخلیه‌ی بخار بر روی دریوش دریچه قفل نشده باشد

• قبل از استفاده برای اولین بار، اجزای جدا شدنی دستگاه را با آب و مواد شوینده بشویید.

۸. دوشاخه را به پریز برق و سوکت را به جایگاه اتصال سوکت وصل نمایید. از اتصال صحیح کابل برق به دستگاه و دوشاخه به پریز برق مطمئن شویید.

۹. کنترل پنل روشن خواهد شد و در حالت آماده به کار قرار می‌گیرد.

دروپوش تخلیه بخار	<b>A</b>
درب	<b>B</b>
واشر نشت‌گیر	<b>C</b>
دروپوش داخلی	<b>D</b>
دستگیره	<b>E</b>
کنترل پنل لمسی	<b>F</b>
بدنه اصلی	<b>G</b>
نگهدارنده ملاقه و کفگیر	<b>H</b>
کابل برق و دوشاخه	<b>I</b>
جایگاه اتصال کابل	<b>J</b>
قابلمه پخت	<b>K</b>
سبد بخاریز	<b>L</b>
قالبهای ماستبندی	<b>M</b>
کفگیر	<b>N</b>
ملaque	<b>O</b>
پیمانه	<b>P</b>

### راهنمای استفاده از دستگاه

- قبل از استفاده برای اولین بار، اجزای جدا شدنی دستگاه را با آب و مواد شوینده بشویید.
- ۱. دستگاه را بر روی سطحی صاف و محکم (بر روی کابینت یا میز) قرار دهید.
- ۲. دستگاه باید حدود ۱۰ سانتیمتر از دیوار، کابینت و سایر وسایل فاصله داشته باشد، تا فضای کافی برای باز کردن درب و بیرون آوردن قابلمه‌ی پخت وجود داشته باشد.



## راهنمای کار با کنترل پنل



باید گزینه "MENU" را به صورت ممتد و پشت سر هم لمس کنید، تا به برنامه‌ی پخت مورد نظر برسد. (مطابق تصویر ۲-۲)

- این گزینه برای تنظیم مدت زمان پخت استفاده می‌شود. برای تنظیم نمودن مدت زمان پخت باید ابتدا برنامه‌ی پخت را از طریق "منو" انتخاب کنید. سپس با استفاده از گزینه‌های "MIN" و "HR" مدت زمان پخت را تنظیم کنید.

- گزینه‌های "HR" و "MIN" برای کاهش و افزایش مدت زمان پخت به کار می‌روند. گزینه‌ی "HR" برای کاهش دادن زمان پخت و گزینه‌ی "MIN"

برای افزایش دادن زمان پخت به کار می‌رود.

- برای افزایش/کاهش سریع و بی‌وقفه‌ی مدت زمان می‌توانید عملکردهای "MIN" و "HR" را لمس کرده و نگه دارید. (مطابق تصاویر ۲-۳، ۲-۴)

با وصل کردن دوشاخه به پریز برق و سوکت به جایگاه اتصال کابل، کنترل پنل روش خواهد شد و دستگاه در حالت امداده به کار قرار می‌کردد. (مطابق تصویر ۲-۱)

**هشدار:** کنترل پنل لمسی دستگاه به صورت اتوماتیک بعد از چند ثانیه غیر فعال می‌شود. توصیه می‌شود که تنظیمات مورد نظر را بدون وقفه اعمال کنید، در صورت غیر فعال شدن کنترل پنل گزینه "cancel" را انتخاب کنید تا مجددًا فعال گردد و قابلیت اجرا کردن تنظیمات را داشته باشد.

### "MENU" منو

- این گزینه برای انتخاب برنامه‌ی پخت به کار می‌رود. با هر بار لمس کردن منو می‌توانید برنامه‌ی پخت مورد نظر را انتخاب کنید، در واقع برای رسیدن به برنامه‌ی پخت مورد نظر

در دسترس می باشد.

### "START"

- این گزینه برای فعال کردن برنامه‌ی پخت انتخابی است و بالمس آن دستگاه با برنامه‌ی تنظیم شده شروع به کار می کند.
- ابتدا از طریق گزینه‌ی "MENU" برنامه‌ی پخت مد نظر را انتخاب کنید و در صورت نیاز با عملکردهای "MIN" و "HR" مدت زمان پخت را تنظیم نمایید. سپس گزینه‌ی "START" را بالمس کرده و به مدت ۲ ثانیه نگه دارید، تا دستگاه با برنامه‌ی انتخابی شما شروع به کار کند.

### KEEP WARM/CANCEL

- این عملکرد جهت فعال نمودن حالت گرم نگهدار به کار می رود. همچنین برای لغو عملیات و برنامه‌ی پخت نیز می توان از این عملکرد استفاده کرد. برنامه‌های پخت به غیر از برنامه‌ی سرخ کردن و ماستیندی بعد از اتمام، به صورت خودکار وارد حالت گرم نگهدار می شوند. پس از پایان یافتن مدت زمان گرم نگه داشتن، دستگاه به صورت خودکار در حالت آماده به کار قرار می گیرد. هنگامی که دستگاه در حالت پخت با برنامه‌ی انتخابی است، با انتخاب و لمس کردن عملکرد "cancel" عملیات لغو شده و دستگاه در حالت آماده به کار خواهد گرفت.
- برای لغو کردن برنامه‌ی انتخابی باید گزینه‌ی مدت ۳ ثانیه "نگه دارید.



### "TEMP"

- این گزینه برای تنظیم درجه حرارت "TEMP" به کار می رود و تنها برای برنامه‌ی سرخ کردن "FRY" در دسترس می باشد.

- برای اعمال تنظیم درجه حرارت پخت ابتدا باید برنامه‌ی سرخ کردن را از طریق "منو" انتخاب نمایید، سپس بالمس گزینه‌ی "TEMP" درجه حرارت را بین ۱۰۰ الی ۱۶۰ درجه‌ی سانتیگراد تنظیم کنید. (مطابق تصویر ۲-۵)

### "PRESET"

- تایمر تأخیر با استفاده از حالت تأخیر می توانید به دستگاه برنامه‌ی زمانی بدھید، تا در ساعت مشخص روشن شود و شروع به کار کند. برای فعال کردن "PRESET" ابتدا برنامه‌ی پخت مورد نظر را تعیین کنید و در صورت امکان مدت زمان و دمای پخت را تنظیم نمایید.

- گزینه‌ی "PRESET" را انتخاب کنید و با استفاده از عملکردهای افزایش/کاهش "MIN" و "HR" مدت زمان تأخیر را تنظیم کنید. سپس "START" را بالمس کرده و به مدت ۲ ثانیه "نگه دارید تا شمارش معکوس آغاز شود. منظر تمام شدن مدت زمان تأخیر باشید، تا دستگاه با برنامه‌ی انتخابی شما شروع به کار کند.

- عملکرد "PRESET" برای تمام برنامه‌های پخت در دسترس می باشد.
- برای انتخاب برنامه‌ی پخت مورد نظر "منو" را بالمس کنید.
- بعد از انتخاب نوع برنامه‌ی پخت، "PRESET" را بالمس کنید تا دستگاه وارد حالت تایmer تأخیر شود.

- صفحه نمایش «ساعت» را نشان میدهد. سپس با استفاده از عملکردهای "MIN" و "HR" ساعت را بین ۱ الی ۲۴ ساعت تنظیم نمایید.
- برای تنظیم دقیقه یک بار دیگر "PRESET" را بالمس کنید، تا امکان تنظیم زمان بین ۱ الی ۵۹ دقیقه فراهم آید.

- طولانی ترین مدت زمان تایمر تأخیر ۲۴ ساعت" می باشد.
- برای لغو کردن برنامه‌ی انتخابی تایمر تأخیر گزینه‌ی "KEEP WARM/CANCEL" را انتخاب کنید.
- عملکرد "PRESET" برای تمام برنامه‌های پخت



## راهنمای استفاده از برنامه‌های پخت "RICE"

### برنامه‌ی پخت خورش "STEW"

- با سه بار لمس کردن گزینه‌ی "منو" برنامه‌ی "STEW" انتخاب می‌شود و شروع به چشمک زدن می‌کند. زمان پیش فرض برای این برنامه "۲ ساعت" است.

- برای تنظیم مدت زمان پخت باید از عملکردهای "MIN" و "HR" استفاده کرد. این برنامه قابلیت تنظیم مدت زمان پخت تا "۸ ساعت" را دارد.

- گزینه‌ی "START" را لمس کنید و به مدت ۲ ثانیه نگه دارید، تا دستگاه با برنامه‌ی انتخابی شما شروع به کار کند.

- پس از به پایان رسیدن مدت زمان پخت، دستگاه بوق زده و به صورت خودکار وارد حالت "گرم نگهدار" می‌شود.

### برنامه‌ی سرخ کردن "FRY"

- با چهار بار لمس کردن گزینه‌ی "منو" برنامه‌ی "FRY" انتخاب می‌شود و شروع به چشمک زدن می‌کند. زمان پیش فرض برای این برنامه "۵ دقیقه" است و امکان تنظیم مدت زمان پخت برای این برنامه در دسترس نمی‌باشد.

- گزینه‌ی "START" را لمس کنید و به مدت ۲ ثانیه نگه دارید، تا دستگاه با برنامه‌ی انتخابی شما شروع به کار کند.

- مقدار روغن نباید از سطح مشخص (سطح ۵ دیواره‌ی داخلی قابلیت پخت) بیشتر باشد. برای تنظیم مدت زمان پخت باید از عملکردهای "MIN" و "HR" استفاده کرد. این برنامه قابلیت تنظیم مدت زمان پخت تا "۱ ساعت" را دارد.

- برای تنظیم درجه حرارت باید از عملکرد "TEMP" استفاده کرد. با لمس "TEMP" می‌توانید درجه حرارت را بین ۱۰۰ الی ۱۶۰ درجه سانتیگراد تنظیم نمود.

- گزینه‌ی "START" را لمس کنید و به مدت ۲ ثانیه نگه دارید، تا دستگاه با برنامه‌ی انتخابی شما شروع به کار کند.

- پس از به پایان رسیدن مدت زمان پخت، دستگاه بوق زده و به صورت خودکار وارد حالت "گرم نگهدار" می‌شود.

### برنامه‌ی پختن نان "BAKE"

- با پنج بار لمس کردن گزینه‌ی "منو" برنامه‌ی "BAKE" انتخاب می‌شود و شروع به

- این برنامه برای پخت برنج به کار می‌رود.

- برای فعال کردن این برنامه باید گزینه‌ی "rice" را انتخاب کرده و به مدت "۳ ثانیه" نگه دارید، تا برنامه‌ی پختن برنج شروع شود.

- برای غیر فعال کردن و لغو برنامه‌ی پخت برنج، کلید "KEEP WARM/CANCEL" را لمس کنید و به مدت "۳ ثانیه" نگه دارید.

- پس از به پایان رسیدن مدت زمان پخت، دستگاه بوق زده و به صورت خودکار وارد حالت "گرم نگهدار" می‌شود.

- این برنامه قابلیت تنظیم مدت زمان و دما را ندارد.

## برنامه‌ی پخت کیک "CAKE"

با یک بار لمس کردن گزینه‌ی "منو" برنامه‌ی "CAKE" انتخاب می‌شود و شروع به چشمک زدن می‌کند. زمان پیش فرض برای این برنامه "۵ دقیقه" است و امکان تنظیم مدت زمان پخت برای این برنامه در دسترس نمی‌باشد.

- گزینه‌ی "START" را لمس کنید و به مدت ۲ ثانیه نگه دارید، تا دستگاه با برنامه‌ی انتخابی شما شروع به کار کند.

- پس از به پایان رسیدن مدت زمان پخت، دستگاه بوق زده و به صورت خودکار وارد حالت "گرم نگهدار" می‌شود.

## برنامه‌ی پخت سوپ "SOUP"

- با دو بار لمس کردن گزینه‌ی "منو" برنامه‌ی "SOUP" انتخاب می‌شود و شروع به چشمک زدن می‌کند. زمان پیش فرض برای این برنامه "۱ ساعت" است.

برای تنظیم مدت زمان پخت باید از عملکردهای "MIN" و "HR" استفاده کرد. این برنامه قابلیت تنظیم مدت زمان پخت تا "۴ ساعت" را دارد.

- گزینه‌ی "START" را لمس کنید و به مدت ۲ ثانیه نگه دارید، تا دستگاه با برنامه‌ی انتخابی شما شروع به کار کند.

- پس از به پایان رسیدن مدت زمان پخت، دستگاه بوق زده و به صورت خودکار وارد حالت "گرم نگهدارنده" می‌شود.

### "PIZZA" برنامه‌ی پیتزا

- با هشت بار لمس کردن گزینه‌ی "منو" برنامه‌ی "PIZZA" انتخاب می‌شود و شروع به چشمک زدن می‌کند. زمان پیش فرض برای این برنامه ۲۵ دقیقه است.
- برای تنظیم مدت زمان پخت باید از عملکردهای "MIN" و "HR" استفاده کرد. این برنامه قابلیت تنظیم مدت زمان پخت تا ۵ دقیقه را دارد.
- گزینه‌ی "START" را لمس کنید و به مدت ۲ ثانیه نگه دارید، تا دستگاه با برنامه‌ی انتخابی شما شروع به کار کند.
- پس از به پایان رسیدن مدت زمان پخت، دستگاه بوق زده و به صورت خودکار وارد حالت "گرم نگه‌دار" می‌شود.

### "YOGHURT" برنامه‌ی ماست‌بندی

- با نه بار لمس کردن گزینه‌ی "منو" برنامه‌ی "YOGHURT" انتخاب می‌شود و شروع به چشمک زدن می‌کند. زمان پیش فرض برای این برنامه ۸ ساعت است.
- برای تنظیم مدت زمان پخت باید از عملکردهای "MIN" و "HR" استفاده کرد. این برنامه قابلیت تنظیم مدت زمان پخت تا ۱۲ ساعت را دارد.
- گزینه‌ی "START" را لمس کنید و به مدت ۲ ثانیه نگه دارید، تا دستگاه با برنامه‌ی انتخابی شما شروع به کار کند.

### "OATMEAL" برنامه‌ی پخت جو

- با ده بار لمس کردن گزینه‌ی "منو" برنامه‌ی "OATMEAL" انتخاب می‌شود و شروع به چشمک زدن می‌کند. زمان پیش فرض برای این برنامه ۳۰ دقیقه است.
- برای تنظیم مدت زمان پخت باید از عملکردهای "MIN" و "HR" استفاده کرد. این برنامه قابلیت تنظیم مدت زمان پخت تا ۱ ساعت را دارد.
- گزینه‌ی "START" را لمس کنید و به مدت ۲ ثانیه نگه دارید، تا دستگاه با برنامه‌ی انتخابی شما شروع به کار کند.
- پس از به پایان رسیدن مدت زمان پخت، دستگاه بوق زده و به صورت خودکار وارد حالت "گرم نگه‌دار" می‌شود.

چشمک زدن می‌کند. زمان پیش فرض برای این برنامه ۳۰ دقیقه است.

- برای تنظیم مدت زمان پخت باید از عملکردهای "MIN" و "HR" استفاده کرد. این برنامه قابلیت تنظیم مدت زمان پخت تا ۱ ساعت را دارد.

- گزینه‌ی "START" را لمس کنید و به مدت ۲ ثانیه نگه دارید، تا دستگاه با برنامه‌ی انتخابی شما شروع به کار کند.

- پس از به پایان رسیدن مدت زمان پخت، دستگاه بوق زده و به صورت خودکار وارد حالت "گرم نگه‌دار" می‌شود.

### "CRUST" ته‌دیگ

- با شش بار لمس کردن گزینه‌ی "منو" برنامه‌ی "CRUST" انتخاب می‌شود و شروع به چشمک زدن می‌کند. زمان پیش فرض برای این برنامه ۱/۳۰ ساعت است.

- برای تنظیم مدت زمان پخت باید از عملکردهای "MIN" و "HR" استفاده کرد. این برنامه قابلیت تنظیم مدت زمان پخت تا ۳ ساعت را دارد.

- گزینه‌ی "START" را لمس کنید و به مدت ۲ ثانیه نگه دارید، تا دستگاه با برنامه‌ی انتخابی شما شروع به کار کند.

- پس از به پایان رسیدن مدت زمان پخت، دستگاه بوق زده و به صورت خودکار وارد حالت "گرم نگه‌دار" می‌شود.

### "PASTA" برنامه‌ی پخت ماکارونی

- با هفت بار لمس کردن گزینه‌ی "منو" برنامه‌ی "PASTA" انتخاب می‌شود و شروع به چشمک زدن می‌کند. زمان پیش فرض برای این برنامه ۸ دقیقه است.

- برای تنظیم مدت زمان پخت باید از عملکردهای "MIN" و "HR" استفاده کرد. این برنامه قابلیت تنظیم مدت زمان پخت تا ۲ دقیقه را دارد.

- گزینه‌ی "START" را لمس کنید و به مدت ۲ ثانیه نگه دارید، تا دستگاه با برنامه‌ی انتخابی شما شروع به کار کند.

- پس از به پایان رسیدن مدت زمان پخت، دستگاه بوق زده و به صورت خودکار وارد حالت "گرم نگه‌دار" می‌شود.



- پس از به پایان رسیدن مدت زمان پخت، دستگاه بوق زده و به صورت خودکار وارد حالت "گرم نگهدار" می‌شود.

**برنامه‌ی فرنی شیر "MILK PORRRIDGE"**  
- با چهارده بار لمس کردن گزینه‌ی "منو" برنامه‌ی "MILK PORRRIDGE" انتخاب می‌شود و شروع به چشمک زدن می‌کند. زمان پیش فرض برای این برنامه ۱۰ دقیقه است.

- برای تنظیم مدت زمان پخت باید از عملکردهای "MIN" و "HR" استفاده کرد. این برنامه قابلیت تنظیم مدت زمان پخت تا ۳۰ دقیقه را دارد.

- گزینه‌ی "START" را بالمس کنید و به مدت ۲ ثانیه نگه دارید، تا دستگاه با برنامه انتخابی شما شروع به کار کند.

- پس از به پایان رسیدن مدت زمان پخت، دستگاه بوق زده و به صورت خودکار وارد حالت "گرم نگهدار" می‌شود.

**برنامه‌ی برنج خیس خورده "SOAKED RICE"**

- با پانزده بار لمس کردن گزینه‌ی "منو" برنامه‌ی "SOAKED RICE" انتخاب می‌شود و شروع به چشمک زدن می‌کند. زمان پیش فرض برای این برنامه ۵ دقیقه است.

- برای این برنامه قابلیت تنظیم مدت زمان پخت در دسترس نمی‌باشد.

- گزینه‌ی "START" را بالمس کنید و به مدت ۲ ثانیه نگه دارید، تا دستگاه با برنامه انتخابی شما شروع به کار کند.

- پس از به پایان رسیدن مدت زمان پخت، دستگاه بوق زده و به صورت خودکار وارد حالت "گرم نگهدار" می‌شود.

**برنامه‌ی گرم کردن مجدد "REHEAT"**

- با شانزده بار لمس کردن گزینه‌ی "منو" برنامه‌ی "REHEAT" انتخاب می‌شود و شروع به چشمک زدن می‌کند. زمان پیش فرض برای این برنامه ۱ ساعت است.

- برای این برنامه قابلیت تنظیم مدت زمان در دسترس نمی‌باشد.

- گزینه‌ی "START" را بالمس کنید و به مدت ۲ ثانیه نگه دارید، تا دستگاه با برنامه انتخابی شما شروع به کار کند.

## "DESSERT" برنامه‌ی دسر

- با یازده بار لمس کردن گزینه‌ی "منو" برنامه‌ی "DESSERT" انتخاب می‌شود و شروع به چشمک زدن می‌کند. زمان پیش فرض برای این برنامه ۱ ساعت است.

- برای تنظیم مدت زمان پخت باید از عملکردهای "MIN" و "HR" استفاده کرد. این برنامه قابلیت تنظیم مدت زمان پخت تا ۴ ساعت را دارد.

- گزینه‌ی "START" را بالمس کنید و به مدت ۲ ثانیه نگه دارید، تا دستگاه با برنامه انتخابی شما شروع به کار کند.

- پس از به پایان رسیدن مدت زمان پخت، دستگاه بوق زده و به صورت خودکار وارد حالت "گرم نگهدار" می‌شود.

## "STEAM" برنامه‌ی بخاریز

- با دوازده بار لمس کردن گزینه‌ی "منو" برنامه‌ی "STEAM" انتخاب می‌شود و شروع به چشمک زدن می‌کند. زمان پیش فرض برای این برنامه ۵ دقیقه است.

- برای تنظیم مدت زمان پخت باید از عملکردهای "MIN" و "HR" استفاده کرد. این برنامه قابلیت تنظیم مدت زمان پخت تا ۱۵ ساعت را دارد.

- گزینه‌ی "START" را بالمس کنید و به مدت ۲ ثانیه نگه دارید، تا دستگاه با برنامه انتخابی شما شروع به کار کند.

- پس از به پایان رسیدن مدت زمان پخت، دستگاه بوق زده و به صورت خودکار وارد حالت "گرم نگهدار" می‌شود.

## "CONGEE" برنامه‌ی کنجی

- با سیزده بار لمس کردن گزینه‌ی "منو" برنامه‌ی "CONGEE" انتخاب می‌شود و شروع به چشمک زدن می‌کند. زمان پیش فرض برای این برنامه ۱ ساعت است.

- برای تنظیم مدت زمان پخت باید از عملکردهای "MIN" و "HR" استفاده کرد. این برنامه قابلیت تنظیم مدت زمان پخت تا ۴ ساعت را دارد.

- گزینه‌ی "START" را بالمس کنید و به مدت ۲ ثانیه نگه دارید، تا دستگاه با برنامه انتخابی شما شروع به کار کند.

### عیب‌یابی

مشکل	علت احتمالی	راه حل
• پلوپر روش نمی‌شود.	• پریز فاقد جریان الکتریکی است. • کابل برق یا دوشاخه معیوب شده‌اند.	• با استفاده از ولت‌متر از وجود برق در پریز مطمئن شوید. • از سالم بودن کابل برق و دوشاخه مطمئن شوید.
کنترل پنل روش نمی‌شود.	• برق در دستگاه جریان ندارد. • برد دستگاه آسیب دیده است.	• کابل برق و دوشاخه را بررسی کنید و از اتصال کامل آنها مطمئن شوید. • به مراکز خدمات پس از فروش ناسا الکتریک مراجعه نمایید.
• المنت گرم نمی‌شود.	• برد دستگاه آسیب دیده است. • فیوز دستگاه سوخته است. • المنت آسیب دیده است.	• به مراکز خدمات پس از فروش ناسا الکتریک مراجعه نمایید.
• برنج کاملاً پخته نمی‌شود.	• نسبت آب و برنج مناسب نیست. • قابلمه پخت به درستی در جایگاه خود قرار نگرفته است و تماس کامل بین المنت و قابلمه پخت برقرار نشده است. • ممکن است شبیئی خارجی مابین قابلمه پخت و المنت قرار گرفته باشد. • قابلمه پخت بر اثر ضربه تغییر شکل داده است. • برد دستگاه آسیب دیده است. • سنسور کار نمی‌کند.	• نسبت آب و برنج را تنظیم کنید. • قابلمه پخت را به درستی درون محفظه داخلی قرار دهید. • محفوظه داخلی و صفحه المنت را بررسی کرده و تغییر نمایید. • به مراکز خدمات پس از فروش ناسا الکتریک مراجعه نمایید.
• برنج سوخته است.	• قابلمه پخت بر اثر ضربه تغییر شکل داده است. • برد دستگاه آسیب دیده است. • سنسور کار نمی‌کند.	• به مراکز خدمات پس از فروش ناسا الکتریک مراجعه نمایید.
• صفحه نمایش خطاهای E1,E2,E3,E4 نشان می‌دهد.	• برد دستگاه آسیب دیده است. • سنسور کار نمی‌کند.	• به مراکز خدمات پس از فروش ناسا الکتریک مراجعه نمایید.



## راهنمای نگهداری قابلمهی پخت

۱. لطفاً از فاشق پلاستیکی یا چوبی برای هم زدن مواد غذایی داخل قابلمه استفاده کنید، در صورت استفاده از فاشق فلزی، مراقب باشید قابلمهی پخت آسیب نیند.

۲. در صورتی که غذا به ته قابلمهی پخت چسبیده باشد، برای چند ساعت داخل قابلمه آب بزیید، سپس آن را بشویید.

۳. به منظور محافظت از پوشش نجسب قابلمهی پخت، لطفاً مواد غذایی را داخل قابلمهی پخت برش ندهید.

۴. برای جلوگیری از پوسیده شدن قابلمهی پخت، داخل آن سرمه نریزید.

## انبار کردن و نگهداری از دستگاه

۰. قبل از بستبندی مجدد محصول، از خشک بودن قطعات و بدنه دستگاه اطمینان حاصل نمایید.

۱. لطفاً پس از اتمام کار با دستگاه، آن را مجدداً بستبندی کنید و در جای خشک و به دور از رطوبت قرار دهید.

## مشخصات فنی دستگاه

۱۰۰۰ وات	توان
۵۰ هرتز	فرکانس
۲۲۰-۲۴۰ ولت	ولتاژ
۵ لیتر	ظرفیت

## گارانتی و خدمات پس از فروش

این محصول دارای ۱۸ ماه گارانتی و ۵ سال خدمات پس از فروش می‌باشد. جهت اطلاعات بیشتر در مورد نحوه فعال‌سازی گارانتی به برگه‌ی ضمانتنامه در انتهای این دفترچه مراجعه کنید یا با شماره‌ی ۰۲۱۴۵۱۱۴ تماس حاصل فرمایید.

## راهنمای تمیز کردن و نگهداری دستگاه

۱. جهت جلوگیری از خطرات احتمالی قبل از تمیز کاری دستگاه، دوشاخه را از پریز برق بیرون آورید و منتظر بمانید تا دستگاه کاملاً خنک شود.

۲. قابلمهی پخت را از محفظه داخلی بیرون آورید و مواد غذایی داخل آن را خالی کنید. سپس با مکم آب و مواد شوینده مناسب آن را بشویید و خشک نمایید.

۳. از شستن قابلمهی پخت با سیم ظرفشویی و ساینده‌های فلزی که باعث خراشیده شدن قابلمهی پخت می‌شود، خودداری کنید.

۴. درپوش داخلی را از درب پلویز جدا کنید.

۵. ابتدا کیره‌های درپوش داخلی را به سمت بالا بکشید و درپوش را از داخل درب بیرون آورید. سپس درپوش داخلی را با آب و مواد شوینده مناسب بشویید.

۶. واشر نشتگیر را که به درپوش داخلی متصل است، با دقت تمیز کنید. تا مواد غذایی لا به لای واشر جا نماند و باعث ایجاد بوی نامطبوع در استفاده‌های بعدی نگردد.

۷. درپوش داخلی، دریچه‌ی تخلیه بخار و درپوش دریچه‌ی تخلیه بخار را بعد از هر بار استفاده بشویید، در غیر این صورت باعث بروی نامطبوع در دستگاه خواهد شد.

۸. دریچه‌ی تخلیه‌ی بخار و درپوش دریچه‌ی تخلیه‌ی بخار نیز قابل جدا شدن هستند. ابتدا درپوش تخلیه‌ی بخار را بردارید، زیر درپوش تخلیه‌ی بخار، دریچه‌ی تخلیه‌ی بخار قرار دارد.

۹. دریچه‌ی تخلیه‌ی بخار قابل جدا شدن است و برای جدا کردن آن کافی است که دریچه‌ی تخلیه‌ی بخار را در خلاف جهت حرکت عقربه‌های ساعت بچرخانید. (در جهت علامت "OPEN" روی درپوش دریچه‌ی تخلیه‌ی بخار)

۱۰. برای تمیز کردن دستگاه هرگز بدنه اصلی را داخل آب یا هر مایع دیگری فرو نبرید. بلکه از پارچه‌ای نمدار و مرطوب برای تمیز کردن بدنه دستگاه استفاده نمایید.

۱۱. از سیم ظرفشویی برای شستشوی بدنه دستگاه، قابلمهی پخت و درپوش داخلی و سایر قطعات دستگاه استفاده نکنید.

کدهای زیر را با تلفن همراه اسکن کنید:

۱. روش استفاده صحیح از محصول را در فیلم آموزشی ببینید.
۲. روش‌های بهره‌مندی از خدمات پس از فروش و فعال‌سازی گارانتی را در وبسایت ناسا سرویس به آدرس [www.nasaservice.com](http://www.nasaservice.com) دنبال کنید.



۲ فعال‌سازی گارانتی و خدمات پس از فروش



۱ فیلم آموزشی استفاده صحیح از دستگاه



🌐 [www.nasa-electric.com](http://www.nasa-electric.com)  
🌐 [www.nasaservice.com](http://www.nasaservice.com)

telegram: [nasa\\_electric\\_company](#)  
Instagram: [nasa\\_electric\\_company](#)

### Clean and maintenance guide

1. To avoid potential hazards before cleaning the appliance, unplug it and wait for the appliance to cool completely.
2. Take the cooking pot out of the inner housing and empty the food inside. Then wash it with water and suitable detergent and dry it.
3. Avoid washing the cooking pot with dishwasher wire and metal abrasives that will scratch the cooking pot.
4. Remove the inner cover from the cooker lid. First, pull the inner cover clamps upwards and pull the lid out of the lid. Then wash the inner cover with water and a suitable detergent.
5. Carefully clean the sealing washer that attaches to the inner cover. So that the food does not stick to the washer and does not cause an unpleasant odor in later uses.
6. Wash the inner cover, the steam evacuate valve and the steam evacuate valve cover after each use, otherwise it will cause an unpleasant odor in the device.
7. The steam evacuate valve and the lid of the steam valve can also be removed. First remove the steam evacuate cover, below the steam evacuate cover is the steam evacuate valve.
8. The steam evacuate valve is detachable and to remove it, it is enough to turn the steam evacuate valve counterclockwise. (In the direction of the "OPEN" mark on the cover of the steam evacuate valve)
9. Never immerse the main body in water or any other liquid to clean the appliance. Instead, use a damp cloth to clean the body of the device.
10. Do not use the dishwasher wire to wash the body of the appliance, the cooking pot and the inner cover and other parts of the appliance.

### Cooking pot maintenance guide

1. Please use a plastic or wooden spoon to stir the food in the pot, if you use a metal spoon, be careful not to damage the cooking

pot.

2. If the food is stuck to the bottom of the cooking pot, pour water into the pot for a few hours, then wash it.
3. To protect the non-stick coating of the cooking pot, please do not cut food into the cooking pot.
4. Do not pour vinegar into the cooking pot to prevent it from rotting.

### Product storage and maintenance

- Before repack the product, make sure that the parts and the body of the device are dry.
- Please repackage the device after finishing work and place it in a dry place away from wet.

### Technical specifications

Power	1000 W
Frequency	50 Hz
Voltage	220-240 V
Capacity	5 L

### Guarantee and after sales service

This device has 18-month guarantee and 5 years after sales service, for more information about guarantee and after sales service condition please read the guarantee sheet in the end of this user manual or call +982145114.

## Troubleshooting

Problem	Possible cause	Solution
<ul style="list-style-type: none"> <li>The multi cooker does not turn on.</li> </ul>	<ul style="list-style-type: none"> <li>There is no electricity inside the socket.</li> <li>The power cord or plug is defective.</li> </ul>	<ul style="list-style-type: none"> <li>Use a voltmeter to make sure there is electricity in the socket.</li> <li>Make sure the power cable and plug are safe.</li> </ul>
<ul style="list-style-type: none"> <li>The control panel does not turn on.</li> </ul>	<ul style="list-style-type: none"> <li>There is no electricity in the device.</li> <li>The board of the device is damaged.</li> <li>Check the power cable and plug and make sure they are fully connected.</li> </ul>	<ul style="list-style-type: none"> <li>Visit NASA Electric after-sales service centers.</li> </ul>
<ul style="list-style-type: none"> <li>The element does not heat up.</li> </ul>	<ul style="list-style-type: none"> <li>The board of the device is damaged.</li> <li>The device fuse is blown.</li> <li>The element is damaged.</li> </ul>	<ul style="list-style-type: none"> <li>Visit NASA Electric after-sales service centers.</li> </ul>
<ul style="list-style-type: none"> <li>The rice is not fully cooked.</li> </ul>	<ul style="list-style-type: none"> <li>The ratio of water and rice is not appropriate.</li> <li>The cooking pot is not in place properly and full contact is not established between the element and the cooking pot.</li> <li>An external object may be located between the cooking pot and the element.</li> <li>The cooking pot has been deformed due to impact.</li> <li>The board of the device is damaged.</li> <li>The sensor does not work.</li> </ul>	<ul style="list-style-type: none"> <li>Adjust the ratio of water and rice.</li> <li>Place the cooking pot properly in the inner compartment.</li> <li>Inspect and clean the inner compartment and element plate.</li> <li>Visit NASA Electric after-sales service centers.</li> </ul>
<ul style="list-style-type: none"> <li>The rice is burnt.</li> </ul>	<ul style="list-style-type: none"> <li>The cooking pot has been deformed due to impact.</li> <li>The board of the device is damaged.</li> <li>The sensor does not work.</li> </ul>	<ul style="list-style-type: none"> <li>Visit NASA Electric after-sales service centers.</li> </ul>
<ul style="list-style-type: none"> <li>The display shows E1-E2-E3-E4 errors.</li> </ul>	<ul style="list-style-type: none"> <li>The board of the device is damaged.</li> <li>The sensor does not work.</li> </ul>	<ul style="list-style-type: none"> <li>Visit NASA Electric after-sales service centers.</li> </ul>

## OATMEAL

- Touching the "Menu" option ten times selects the "OATMEAL" program and starts blinking. The default time for this app is "30 minutes".
- The "MIN" and "HR" functions must be used to set the cooking time. This program has the ability to set the cooking time to "1 hour".
- Touch and hold the "START" option for 2 seconds, until the device starts working with the program of your choice.
- At the end of the cooking time, the device beeps and automatically enters the "warm retainer" mode.

## DESSERT

- Touching the "Menu" option eleven times selects the "DESSERT" program and starts blinking. The default time for this app is "1 hour".
- The "MIN" and "HR" functions must be used to set the cooking time. This program has the ability to set the cooking time to "4 hours".
- Touch and hold the "START" option for 2 seconds, until the device starts working with the program of your choice.
- At the end of the cooking time, the device beeps and automatically enters the "warm retainer" mode.

## STEAM

- Touching the "Menu" option twelve times selects the "STEAM" program and starts blinking. The default time for this app is "5 minutes".
- The "MIN" and "HR" functions must be used to set the cooking time. This program has the ability to set the cooking time to "1 hour".
- Touch and hold the "START" option for 2 seconds, until the device starts working with the program of your choice.
- At the end of the cooking time, the device beeps and automatically enters the "warm retainer" mode.

## CONGEЕ

- Touching the "Menu" option thirteen times selects the "CONGEЕ" program and starts blinking. The default time for this app is "1 hour".
- The "MIN" and "HR" functions must be used

to set the cooking time. This program has the ability to set the cooking time to "4 hours".

- Touch and hold the "START" option for 2 seconds, until the device starts working with the program of your choice.
- At the end of the cooking time, the device beeps and automatically enters the "warm retainer" mode.

## MILK PORRIDGE

- Touching the "Menu" option fourteen times selects the "MILK PORRIDGE" program and starts blinking. The default time for this app is "10 minutes".
- The "MIN" and "HR" functions must be used to set the cooking time. This program has the ability to set the cooking time up to "30 minutes".
- Touch and hold the "START" option for 2 seconds, until the device starts working with the program of your choice.
- At the end of the cooking time, the device beeps and automatically enters the "warm retainer" mode.

## SOAKED RICE

- Touching the "Menu" option fifteen times selects the "SOAKED RICE" program and starts blinking. The default time for this app is "25 minutes".
- The ability to set the cooking time is not available for this program.
- Touch and hold the "START" option for 2 seconds, until the device starts working with the program of your choice.
- At the end of the cooking time, the device beeps and automatically enters the "warm retainer" mode.

## REHEAT

- By touching the "Menu" option sixteen times, the "REHEAT" program is selected and starts blinking. The default time for this app is "20 minutes".
- The ability to set the duration is not available for this program.
- Touch and hold the "START" option for 2 seconds, until the device starts working with the program of your choice.

ability to set the cooking time to "8 hours".

- Touch and hold the "START" option for 2 seconds, until the device starts working with the program of your choice.
- At the end of the cooking time, the device beeps and automatically enters the "warm retainer" mode.

### **FRY**

- Touching the "Menu" option four times selects the "FRY" program and starts blinking. The default time for this app is "30 minutes".
- The lid of the rice cooker must be open when frying, do not close the lid too much.
- The amount of oil should not be more than the specified level (level 5 of the inner wall of the cooking pot).
- The "MIN" and "HR" functions must be used to set the cooking time. This program has the ability to set the cooking time to "1 hour".
- The "TEMP" function must be used to adjust the temperature. By touching "TEMP" you can adjust the temperature Between 100 to 160 degrees Celsius.
- Touch and hold the "START" option for 2 seconds, until the device starts working with the program of your choice.
- At the end of the cooking time, the device beeps and automatically enters the "warm retainer" mode.

### **BAKE**

- Touching the "Menu" option five times selects the "BAKE" program and starts blinking. The default time for this app is "30 minutes".
- The "MIN" and "HR" functions must be used to set the cooking time. This program has the ability to set the cooking time to "1 hour".
- Touch and hold the "START" option for 2 seconds, until the device starts working with the program of your choice.
- At the end of the cooking time, the device beeps and automatically enters the "warm retainer" mode.

### **CRUST**

- Touching the "Menu" option six times selects the "CRUST" program and starts blinking. The default time for this app is "1.30 hours".

- The "MIN" and "HR" functions must be used to set the cooking time. This program has the ability to set the cooking time to "2 hours".

- Touch and hold the "START" option for 2 seconds, until the device starts working with the program of your choice.
- At the end of the cooking time, the device beeps and automatically enters the "warm retainer" mode.

### **PASTA**

- Touching the "Menu" option seven times selects the "PASTA" program and starts blinking. The default time for this app is "8 minutes".
- The "MIN" and "HR" functions must be used to set the cooking time. This program has the ability to set the cooking time to "20 minutes".
- Touch and hold the "START" option for 2 seconds, until the device starts working with the program of your choice.
- At the end of the cooking time, the device beeps and automatically enters the "warm retainer" mode.

### **PIZZA**

- Touching the "Menu" option eight times selects the "PIZZA" app and starts blinking. The default time for this app is "25 minutes".
- The "MIN" and "HR" functions must be used to set the cooking time. This program has the ability to set the cooking time up to "50 minutes".

Touch and hold the "START" option for 2 seconds, until the device starts working with the program of your choice.

- At the end of the cooking time, the device beeps and automatically enters the "warm retainer" mode.

### **YOGHURT**

- Touching the "Menu" option nine times selects the "YOGHURT" program and starts blinking. The default time for this app is "8 hours".
- The "MIN" and "HR" functions must be used to set the cooking time. This program has the ability to set the cooking time to "12 hours".
- Touch and hold the "START" option for 2 seconds, until the device starts working with the program of your choice.

- Select the “PRESET” option and set the delay time using the “MIN” and “HR” increase/decrease functions. Then touch “START” and hold for “2 seconds” to start the countdown. wait for the latency to expire, for the device to start working with the program of your choice.
- The “PRESET” function is available for all cooking applications.
- Touch “Menu” to select the desired cooking program.
- After selecting the type of playback program, touch “PRESET” until the device enters the delay timer mode.
- Displays the “Clock” display. Then use the “HR” and “MIN” functions to set the clock between 1 and 24 hours.
- Touch “PRESET” again to set the minute, to set the time between 1 and 59 minutes.
- The longest delay timer is “24 hours”.
- Select “KEEP WARM/CANCEL” to cancel the delay timer program.

## **START**

- This option is optional for activating the cooking program, and by touching it, the device starts working with the set program.
- First, select the desired cooking program through the “MENU” option and, if need, set the cooking time with the “HR” and “MIN” functions. Then touch and hold the “START” option for 2 seconds, to start the device with the program of your choice. (as shown in Figure 2-7)

## **KEEP WARM/CANCEL**

- This function is used to activate the warm-up mode. This function can also be used to cancel operations and programs. Roasting programs, except for the frying and yoghurt program after finishing, automatically enter the hot state.
- At the end of the warm-up period, the appliance automatically goes into operation. When the appliance is in cooking mode with the selected program, by selecting and touching the “cancel” function, the operation is canceled and the appliance will be ready for operation.
- To cancel the selected program, touch and hold “KEEP WARM/CANCEL” and hold for “2 seconds”. (as shown in Figure 2-8)

## **Baking programs guide**

### **RICE**

- This program is used for cooking rice. - To activate this program, you must select the “RICE” option and hold for “2 seconds” to start the rice cooking program.
- To deactivate and cancel the rice cooking program, touch and hold the “KEEP WARM/CANCEL” button for “2 seconds”.
- At the end of the cooking time, the device beeps and automatically enters the “warm retainer” mode.
- This program does not have the ability to adjust the duration and temperature.

### **CAKE**

- Touching the “Menu” option once selects the “CAKE” program and starts blinking. The default time for this program is “50 minutes” and it is not possible to set the cooking time for this program.
- Touch and hold the “START” option for 2 seconds, until the device starts working with the program of your choice.
- At the end of the cooking time, the device beeps and automatically enters the “warm retainer” mode.

### **SOUP**

- Double-tapping the “Menu” option selects the “SOUP” program and starts blinking. The default time for this app is “1 hour”.
- The “MIN” and “HR” functions must be used to set the cooking time. This program has the ability to set the cooking time to “4 hours”.
- Touch and hold the “START” option for 2 seconds, until the device starts working with the program of your choice.
- At the end of the cooking time, the device beeps and automatically enters the “warm retainer” mode.

### **STEW**

- Touching the “Menu” option three times selects the “STEW” program and starts blinking. The default time for this app is “2 hours”.
- The “MIN” and “HR” functions must be used to set the cooking time. This program has the

## Working with control panel guide



- By connecting the plug to the power outlet and socket to the cable connector, the control panel will turn on and device will be in standby mode. (As shown in Figure 1-2)

**Warning:** The device's touch control panel is automatically deactivated after a few seconds. It is recommended that you apply the settings without interruption. If the control panel is disabled, select the "cancel" option to reactivate and enable the settings.

### MENU

- This option is used to select the cooking program. Each time you touch the menu, you can select the desired cooking program. In fact, to reach the desired cooking program, you have to touch the "MENU" option continuously, one after the other, to reach the desired cooking program. (as shown in Figure 2-2)

### HR and MIN

- This option is used to set the cooking time. To set the cooking time, you must first select the cooking program from the "Menu". Then set the cooking time using the "HR" and "MIN" options.

- The "HR" and "MIN" options are used to reduce or increase the cooking time.

- The "HR" option is used to reduce the cooking time and the "MIN" option is used to increase the cooking time.
- You can touch and hold the "HR" and "MIN" functions to increase the time quickly and continuously. (as shown in Figures 2-3, 2-4)

### TEMP

- This option is used to set the "TEMP" temperature and is only available for the "FRY" frying program.
- To set the cooking temperature, you must first select the frying program from the "menu", then touch the "TEMP" option to set the temperature Between 100 to 160 degrees Celsius. (as shown in Figure 2-5)

### PRESET

- Using the delay mode, you can schedule the device to turn on at a specific time and start working. To activate "PRESET", first determine the desired cooking program and, if possible, set the cooking time and temperature.

1-1



1-6



1-2



1-5



1-3



1-4



<b>A</b>	Steam evacuate cover
<b>B</b>	LID
<b>C</b>	Leaking washer
<b>D</b>	Inner cover
<b>E</b>	Handle
<b>F</b>	Control panel
<b>G</b>	Main body
<b>H</b>	Ladle & spatula holder
<b>I</b>	Cable & plug
<b>J</b>	Connector cable
<b>K</b>	Cooking pot
<b>L</b>	Steam basket
<b>M</b>	Yoghurt cups
<b>N</b>	Spatula
<b>O</b>	Ladle
<b>P</b>	Measure cup

1. Place the device on a flat and firm surface (on a cabinet or table). (as shown in Figures 1-1, 1-2)
  - The device should be about 10 cm away from the wall, cabinets and other appliances, so that there is enough space to open the lid and take out the cooking pot.
2. Press the lid button to open the cooker lid and remove the cooking pot from the inside of the appliance. (as shown in Figure 1-3)
3. Pour the desired food into the cooking pot and put the pot in the device.
  - The maximum cooking capacity of the pot is "5 liters" and its usable capacity is "4 liters".
  - There is an accurate calibration on the inside wall of the cooking pot, which is used to measure the amount of water and food. Note that the amount of water and food in the cooking pot should not be more than the "MAX" line on the cooking pot. (as shown in Figure 1-4)
4. Put the pot in its place on the element. Before placing the pot on the element, make sure that there are no objects on the element and inside the inner housing. (as shown in Figure 1-5)
5. Attach the inner cover to the cooker lid in the right direction (leaking washer facing out). (as shown in Figure 1-6)
  - First insert the two latches on the inner cover into the corresponding grooves on the lid, then push the two inner cover clamps down to secure it in place.
6. Push the device lid down until a tick is heard.
7. Check the steam evacuate valve and its lid for proper placement. If the steam evacuate valve on the valve cover is not locked, there is a possibility of water spilling from the appliance during cooking.
8. Connect the plug to the mains socket and connect the socket to the connec for cable. Make sure the power cord is properly connected to the device and plugin socket.
9. The control panel will turn on and be in stand-by mode.

### Using the device guide

- Before using for the first time, wash the removable parts of the device with water and detergent.

remote-control system or a separate timer.

**25.** Before cleaning the appliance to prevent burns, first turn it off, then unplug it and wait for the appliance to cool down.

**26.** When working with the device for the first time, you may notice an unusual odor. This is normal and this problem will be solved after using the device several times.

### Device parts & accessories



## Important safety warnings

Please read important safety warnings, install the device parts guide and the device guide.

- 1.** Plug in and make sure the voltage of home socket is match with this product.
- 2.** This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- 3.** Children should be supervised and restricted to ensure that they do not play with the device.
- 4.** This device is designed for domestic and similar purposes and is not suitable for industrial use.
- 5.** Before using the appliance for the first time completely clean parts that contact foods.
- 6.** If any problems or breakdowns in any of the components of device, including the power cable and plug, never use the appliance and immediately contact one of the nearest certified NASA Electric after-sales service centers or send the device to the center.
- 7.** In case of failure of a part of the device, do not replace it with similar parts and make be sure to contact NASA Electric after sales service center. (Please call **+982145114** for more information.)
- 8.** Do not use this device in places where there is no ground wire.
- 9.** Use only the main cooking pot of the device, do not use non-standard pots at all.
- 10.** Do not switch on the appliance before placing it in the cooking pot or while the pot is still empty.
- 11.** Before starting cooking, make sure that the evacuate valve is installed correctly.
- 12.** Do not move the device while working. If you need to replace it, turn off the appliance first, then unplug it.
- 13.** To avoid the risk of electric shock, never connect the plug to the socket with a wet hand and do not touch the body of the device.
- 14.** When using the device, the body of the device heats up and there is a possibility of steam escaping from the evacuate valve. To prevent possible damage, observe the standard distance from the body and the steam evacuate valve of the device.
- 15.** When the appliance is switched on, never cover the steam evacuate valve or the body of the appliance with a towel or any other object.
- 16.** Do not use this device with flammable, explosive agents or in humid environments.
- 17.** To protect the lid of the pot and prevent it from deforming, wash the rice or other food in another container, then pour it into the cooking pot.
- 18.** Make sure that rice or any other food is not on the element under the cooking pot. If present, first clean it, then place the pot inside the appliance.
- 19.** Before using the appliance, make sure that the cooking pot is properly placed inside the appliance. There must be a complete connection between the element and the cooking pot.
- 20.** Regularly wash the inner cover and leaking washer after each use to prevent odors caused by food contamination.
- 21.** If the device is not used for a long time, turn off the device first. Unplug the appliance and keep it in a dry, ventilated place.
- 22.** Never use the appliance if the power cord fails, as this may result in electric shock.
  - If necessary, purchase the cable from an certified NASA Electric after-sales service center. The cable should never be repaired or replaced by the person himself.
- 23.** When the cooker is on, do not open the lid. When the cooking program is complete, unplug the appliance, then open the lid.
- 24.** Clean the steam evacuate valve after each use to prevent the steam evacuate valve from clogging.

\* This device is not intended to work with a

Contents	Page
Important safety warnings.....	3
Device parts & accessories.....	4
Using the device guide.....	5
Working with control panel guide.....	7
Baking programs guide.....	8
Troubleshooting.....	11
Clean and maintenance guide.....	12
Technical specifications.....	12
Guarantee and after sales service.....	12



**NS-3074**

Multi-functional  
cooker



## NASA Electric Multi-Functional Cooker NS-3074 user manual



Thank you for your tact and trust in the NASA electric brand.  
This user manual has been prepared for suitable use as well as better maintenance of device. Please read carefully before using the appliance and keep it well for next uses.





How to use the product

After sales service

ISO MULTIFUNCTIONAL COOKER  
MODEL NS-3074